Coniq single lever

abode



Coniq single lever

General Advice:

- These instructions are intended as a guide only, if you are in any doubt, you should seek the advice of a qualified professional.
- Take care not to mark finished parts with screwdrivers or other tools.
- Use a pair of rubber gloves to get a better grip on decorative hand tight parts.
- Ensure all parts are reassembled tightly.
- After maintenance test that all assemblies are watertight and function correctly.
- Always isolate the hot and cold-water supplies before starting any maintenance, once isolated you should drain any residual water from your system.

To replace the valve:

1. Remove cover (C1) with a small precision screwdriver to expose grub screw (C2).
2. Unscrew grub screw (C2) in an anticlockwise direction using a 2.5mm A/F allen key.
3. Pull handle (C3) away from tap body (B1).
4. Remove shroud (C4) which should contain O ring (C5)
5. Pull out indices ring (C6), note blue is at the top.
6. Remove retaining nut (C7) in an anticlockwise direction using an adjustable spanner.
7. Remove valve (C8) and replace with the new one and assemble in reverse order.

Important Note:

Ensure the locating lugs on the back of valve (C8) align with the holes inside the tap body (B1) when reassembling.

To replace the spout o-rings:

1. Remove the grub screw (B2) on the back of body (B1) using a 2.5mm A/F allen key.
2. Pull the spout (A2) vertically away from the tap body (B1).
3. Remove O-rings (A4) using a precision screwdriver.
4. Clean the spout base (A4) with a soft wet cloth.
5. Replace the O-rings (A4).
6. Typically, the PTFE rings (A3 & A5) do not wear, replace if necessary.
7. Reassemble the tap in reverse order.

Important Note: Top PTFE ring (A3) has a gap; this needs to be aligned with grub screw (B2) during reassembly.

To clean the aerator:

1. Hold the spout (A2) firmly.
2. Unscrew the aerator housing (A1) by hand using a coin.
3. Clean the aerator (A2).
4. Reassemble the tap in the reverse order.