

SPC Flooring Scotia & T-Joint

Installation Instructions

These profiles are designed to provide a neat finishing detail to SPC flooring installations while maintaining the necessary allowance for expansion and contraction.

Before Installation

Ensure the flooring has been fully installed and the surfaces are clean, dry and free from dust or debris.

Always maintain the required expansion gap specified in the SPC flooring installation instructions. Scotia and T-joint profiles must not prevent the flooring from expanding or contracting.

Installing Scotia

1. Measure & Cut

Measure the required length and cut the Scotia to size using a suitable fine-tooth saw. Mitre-cut external and internal corners where required.

2. Dry Fit

Position the Scotia around the perimeter and check the fit before applying adhesive.

3. Apply Adhesive

Apply a suitable high-strength adhesive to the wall, skirting board or other fixed vertical surface.

Do not bond the Scotia directly to the SPC flooring.

4. Position & Secure

Press the Scotia firmly into position, ensuring it covers the expansion gap without restricting movement of the flooring.

5. Allow to Cure

Remove excess adhesive immediately and allow to cure in accordance with the adhesive manufacturer's instructions.

Installing the T-Joint

1. Measure & Cut

Measure the required length and cut the T-joint to size using a suitable fine-tooth saw.

2. Check the Expansion Gap

Ensure there is sufficient space between the two flooring areas for the central section of the T-joint while maintaining the required expansion allowance.

3. Dry Fit

Position the T-joint centrally over the gap and check that both sides adequately cover the flooring edges.

4. Apply Adhesive

Apply a suitable high-strength adhesive to the subfloor beneath the central section of the profile.

Do not bond the T-joint directly to the SPC flooring or completely fill the expansion gap with adhesive.

5. Fit the Profile

Press the T-joint firmly into position. Ensure the flooring remains free to expand and contract beneath both sides of the profile.

6. Allow to Cure

Remove excess adhesive immediately and allow the adhesive to fully cure before exposing the area to foot traffic.

Important

- Never screw or nail through the SPC flooring.
- Never fix Scotia directly to the floating floor.
- Do not restrict the flooring's natural movement.
- Maintain the specified expansion allowance at all times.
- Dry-fit all profiles before applying adhesive.
- Use an adhesive suitable for the profile and installation surface.
- Follow the adhesive manufacturer's curing instructions.

Remember: Scotia should be fixed to the wall/skirting, while the T-joint should be fixed to the subfloor — never to the floating SPC floor itself.