

## **SHERWOOD CLASSIC & ORIGINAL BATH PANELS**

### **FITTING INSTRUCTIONS**

**Baths are usually set up to 525mm high. The complete panel comprises a main panel 450mm deep and a plinth 125mm deep providing a maximum overall panel height of 550mm.**

**The front panel should then be placed in position, ensuring the lipped edge is located between the roll of the bath and the bath frames.**

**The panel can then be secured to the plinth using screws, ensuring the overall height of the panel and plinth is correct. We would recommend 3 screws, 1 in the centre and 1 at near to each end. (Screws not provided )**

**The plinth should be secured to a batten at floor level, ensuring alignment with the bath.**

**If an end panel is required, the same procedure should be followed, with the end panel fitting behind the front panel.**

**If either the front or end panel need to be cut during installation, please ensure all cut edges are re-sealed.**

### **CARE INSTRUCTIONS**

**If at any point the panel or plinth have to be cut to suit a particular bath length or height, or to aid installation, then any cut surface must be re-sealed prior to installation.**

**Failure to comply with this instruction may result in the MDF core absorbing water and the surface lifting and blistering.**