



Installation instructions

- 1、 Docking connector interface
- 2、 Put the connector into the inside
- 3、 Place the lamp on the bracket
- 4、 Tighten the screws

Installation is complete

