

Exposed bath pop up waste Chrome – 25.0001



1. Remove chrome pipe from plug & trap (B).
2. Fit trap B to waste hole of bath using adjuster (C) If required for extra thick bath.
3. Cut trap end of waste pipe (B) to required length and fit trap
4. Remove overflow chrome handle trim from pipe & fixing
5. Push pipes (A) & (B) together at required height for overflow.
6. Secure overflow to bath with handle trim. Use adjuster (C) if required for extra thick baths.
7. Push overflow handle to spindle.

Helpline: - 01452 317 890

Mon – Fri

8.00am – 5.00pm