

INSTALLATION INSTRUCTIONS

1. Cut out template.
2. Fold it along the fold line, position on countertop and fix it. (Fig. 2)
3. Cut the countertop according to the template.
4. Fit brassware to the basin.
5. Locate basin in countertop.
6. Remove the basin.

For Marble Countertop: From the marked place drill a $\Phi 16$ mm hole with a depth of 15 mm. Fill the hole with marble binder and, perpendicularly push the head of the screw in it. Wait until it's solidified.

Before locating the basin, apply sealant to the rim of the basin and countertop. Locate basin with it's fittings in countertop. Press all around it for good seal.

IMPORTANT NOTICE TO INSTALLER

Please check the sizing and dimensions of this template before use. Due to different printing techniques the actual size may differ to that shown.

We regret we are unable to accept any responsibility for work top surfaces incorrectly cut.