



INSTALLATION

- 1. Through the O-ring into the flexible hose of the body underside, put the body into the hole.
- 2. Put the rubber washer into the flixble hose, and use the metal washer and lock nut to screw the body.

after that screw off the screws.

Fitting the waste nuit

Unscrew the upper rubber washer, lower rubber washer and lower lock nut. Put the upper waste outlet into the monobasin.

After that, screw the upper rubber washer and lower rubber washer into theupper waste outlet, screw off the lower lock nut to fix the upper waste outlet.