

Installation Instructions

27.9561/27.0561/27.0571	Belgravia 1&2TH Basin & Pedestal
27.0601/27.9601/27.0611	Cheltenham 1&2TH Basin & Pedestal
27.0341/27.9341/27.0351	Kompact 1&2TH Basin & Pedestal
27.0831/27.0851/27.0841	Cheverney Basin 1&2TH & Pedestal
27.0911/27.941	Type 55 Corner Basin 1&2TH
27.0691/27.9691/27.0681	Tamarind 465 Basin 1&2TH
27.0661/27.9661/27.0681	Tamarind 560 Basin 1&2TH
27.0451/27.9451/27.0461	Tempo Basin 1&2TH & Pedestal
27.0781/27.9711/27.0531	Ferarra 400 Basin 1&2TH & Pedestal

1. Place the basin on the pedestal and move into position in your bathroom. If fixing the basin to the wall please use fixing holes as shown in (picture A).
2. Mark the positions of the pedestal and its screw holes onto the floor. Also mark the position of the basin fixing holes on the wall.
3. Now remove the basin & pedestal. Drill pilot holes for the floor fixing screws and drill and plug the wall for basin fixing screws.
4. Adjust the water and waste pipes as necessary.
5. Reposition the pedestal and screw it into place. Don't drive the screws fully home yet.
6. Position the basin, checking that it's level (use a spirit level) and adjust if you need to. Then screw the basin to the wall.
7. Tighten the pedestal screws. Connect the waste pipe to the trap and the flexible connectors to the waste pipes.
8. Turn on the water and check for leaks. If there are leaks then check the connectors and tighten it necessary.

Picture A:

