

Installation Instructions

27.0891/27.0901
27.0361/27.9361

Type55 Semi Recessed Basin 1&2TH
Kompact Reduced Depth SR Basin
1&2TH

IMPORTANT NOTICE TO INSTALLER: Please check the sizing before use. We are unable to accept any responsibility for work top surfaces incorrectly cut.

1. Cut out the SR template which is supplied with the basin.
2. Fold it along the fold line, position on countertop and it (picture 1).
3. Cut the countertop according to the template.
4. Fit brassware to the basin.
5. Locate and fit in countertop.

For marble countertop: from the marked place drill a 16mm hole with a depth of 15mm. Fill hole with marble binder and, perpendicularly push the head of the screw in it. Wait until it's solidified. Before locating the basin, apply sealant with it's brassware in place on countertop. Press all around it for good seal.

Picture 1

