

<p>Elbow</p> <p>Hand shower</p> <p>Sliding bar</p> <p>Shower hose</p> <p>Washers</p> <p>Screws</p> <p>Plugs</p>	<p>1.Take off the cover of the wall brackets.</p>	<p>2.Drill the holes on the wall and put the plugs,then fix the sliding bar onto the wall.</p>	
<p>3.Put the covers onto the wall brackets.</p>	<p>4.Connect the hand shower with hose.</p>	<p>5.The hex aut side of hose connect to the faucets.</p>	<p>6.Finish.</p>