



Eastbrook Road, Gloucester GL4 3DB
Technical Helpline: 01452 317890
email: technical@eastbrookco.com

READ THESE INSTRUCTIONS BEFORE PROCEEDING AND GIVE THESE INSTRUCTIONS TO THE END USER.

THIS FURNITURE MUST BE INSTALLED BY A TRAINED FITTER WHO HAS EXPERIENCE OF FITTING FURNITURE IN BATHROOMS.

CHECK ALL PRODUCTS CAREFULLY BEFORE FITTING. DO NOT FIT ANY DEFECTIVE OR DAMAGED PRODUCT. CONTACT YOUR SUPPLIER IMMEDIATELY.

THE LOCATION WHERE THE FURNITURE IS FITTED SHOULD BE WELL VENTILATED. THIS FURNITURE IS INTENDED TO WITHSTAND NORMAL HUMIDITY FOUND IN BATHROOMS. IT MUST NEVER BE EXPOSED TO DIRECT WATER SPLASHING OR SOAKING FROM SHOWER HEADS, BATHWATER OR OTHER WATER OUTLET. ALWAYS DRY IMMEDIATELY IF THE FURNITURE IS WET.

DO NOT COMPRESS OR BUTT-UP ANY CARCASE TO A WALL OR OTHER OBJECT AS THIS CAN ADVERSELY AFFECT THE DOORS AND CAN CAUSE STRESS CRACKS IN THE LACQUER FINISH.

ANY CUT EDGES MUST BE EFFECTIVELY RE-SEALED TO AVOID DAMP PENETRATION. FAILURE TO DO THIS WILL NULLIFY THE GUARANTEE.

NEVER USE STRONG DETERGENTS OR ABRASIVE CLEANERS AS THESE CAN DAMAGE THE FURNITURE AND THE TOPS. WIPE WITH A WET CLOTH AND A MILD LIQUID CLEANER.

NARROW DEPTH UNITS MUST BE SECURED BACK TO THE WALL. DO NOT TRY TO FIT ANY TOP TO THESE UNITS UNTIL THEY ARE PROPERLY FIXED AND SECURE.

WHERE BASINS ARE FITTED TO THE FURNITURE, THE SURFACES BETWEEN THE BASIN AND THE TOP OF THE FURNITURE MUST BE COMPLETELY SEALED WITH SILICONE.

ANY UNITS AND/OR TOPS THAT ARE BEING INSTALLED TOGETHER MUST BE TESTED TOGETHER PRIOR TO ANY CUTTING, FIXING OR SEALING TO ENSURE THAT BOTH THE INSTALLER AND THE END CUSTOMER ARE SATISFIED WITH THE SUITABILITY OF THE FIT FOR THEIR INTENDED PURPOSE.

WHEN USING THE OSLO CISTERN UNIT (Code 1.287) IN A CORNER INSTALLATION, FOLLOW THE INSTRUCTIONS PROVIDED WITH THE OSLO CORNER CISTERN TOP (Code 1.267).

VERSION 11