

POWER STRIP INSTALLATION

1. THE POWER STRIP CAN BE MOUNTED ON THE TOP, BOTTOM, OR SIDE BACK FLANGES OF THE CABINET BODY.
2. IF IT IS MOUNTED TO THE TOP OR BOTTOM THERE MAY BE AN INTERFERENCE WITH EQUIPMENT MOUNTED TO THE ENDS OF THE EQUIPMENT RAILS. THIS WILL ONLY HAPPEN IF THE EQUIPMENT EXTENDS TO THE BACK OF THE CABINET.

IF POWER STRIP IS MOUNTED ON HINGE SIDE OF CABINET IT MUST BE DONE WITH BACK PANEL REMOVED

POWER STRIP

8-32 X 7/16 FLAT HEAD SCREW
2 PLACES

MOUNTING HOLES

MOUNTING HOLES

REAR OF CABINET
BACK PANEL NOT SHOWN

CPI CHATSWORTH PRODUCTS, INC.

INSTALLATION -
INSTRUCTIONS, POWER
STRIP, CUBE IT CAB

THIS DRAWING CONTAINS INFORMATION PROPRIETARY TO CHATSWORTH PRODUCTS, INC. ANY REPRODUCTION DISCLOSURE OR USE OF THIS DRAWING IS EXPRESSLY FORBIDDEN EXCEPT AS AGREED TO IN WRITING BY CHATSWORTH PRODUCTS, INC.