

TIMCO

COREFIX


Dot & Dab Wall Fixing Solved!



Lightweight/thermal blockwork



All types of brick & blockwork



COREFIX is suitable for mounting TVs, radiators and cabinets onto Dot & Dab walls, plasterboard over all types of brick and blockwork.



TV Brackets



Radiators




Cabinets

INSTALL IN JUST 5 EASY STEPS!



1. Drill hole to required depth using 10mm masonry drill bit. Turn off hammer drill for aerated blocks.




2. Blow to ensure all debris and dust has been removed from the hole.



3. Gently tap plug into place until flange contacts the plasterboard.



4. Then tap metal core into place.



5. Screw fixture to the wall with supplied screw.

COREFIX 100

5.0 x 100mm Screw
Max Fixture Thickness - 10mm

Available in:

Box of 24

Code: CFX024T

Box of 4

Code: CFX004T

Box of 6

(Drill bit included)

Code: CFX006RVT

COREFIX 120

5.0 x 120mm Screw
Max Fixture Thickness - 30mm

Available in:

Box of 24

Code: CFX024PT

Box of 4

Code: CFX004PT



Timber Battens



Shelves



Warning: Always check for cables and pipes before drilling and use suitable protective equipment.