

Measurement Chart

STYLE NO. 4030 ACTIVE STRETCH SHIRT

	XS	S	M	L	XL	2XL	3XL	4XL	5XL
½ chest width		51	54	57	60	63	66		
Front length		74	75	76	77	78	79		
Back length		75	76	77	78	79	80		
Center back to end of sleeve		86,5	88,5	90,5	92,5	94,5	96,5		

All measurements are in cm before washing.