


AIR DIE GRINDER

83769 - DAT-ADG SPARE PARTS DRAWING/LISTING



Key No.	Part No.	Stock No.	Description
1	YDAT-ADG-1	00167	Housing
2	YDAT-ADG-2	00168	Trigger
3	YDAT-ADG-3	00169	Lever
4	YDAT-ADG-4	00170	Spring
5	YDAT-ADG-5	00171	Pin
6	YDAT-ADG-6	00172	Trigger Pin
7	YDAT-ADG-7	00173	Soft Grip
8	YDAT-ADG-8	00174	O-Ring
9	YDAT-ADG-9	00175	O-Ring
10	YDAT-ADG-10	00176	Valve Stem
11	YDAT-ADG-11	00177	Spring
12	YDAT-ADG-12	00178	O-Ring
13	YDAT-ADG-13	00180	Valve Plug
14	YDAT-ADG-14	00181	Valve Bush
15	YDAT-ADG-15	00182	O-Ring
16	YDAT-ADG-16	00183	Exhaust Deflector
17	YDAT-ADG-17	00184	O-Ring
18	YDAT-ADG-18	00185	Air Regulator
19	YDAT-ADG-19	00186	Set Plate
20	YDAT-ADG-20	00188	O-Ring
21	YDAT-ADG-21	00189	Set Plate
22	YDAT-ADG-22	00190	Gasket
23	YDAT-ADG-23	00191	Air Inlet
24	YDAT-ADG-24	00192	Housing Cover
25	YDAT-ADG-25	00193	Gasket
26	YDAT-ADG-26	00194	Bearing

Key No.	Part No.	Stock No.	Description
27	YDAT-ADG-27	00196	Rear Plate
28	YDAT-ADG-28	00197	Pin
29	YDAT-ADG-29	00198	Rotor
30	YDAT-ADG-30	00199	Rotor Blade
31	YDAT-ADG-31	00200	Cylinder
32	YDAT-ADG-32	00201	Rotor Collar
33	YDAT-ADG-33	00203	Front Plate
34	YDAT-ADG-34	00204	Pin
35	YDAT-ADG-35	00205	Bearing
36	YDAT-ADG-36	00206	Angle Gear
37	YDAT-ADG-37	00207	Bush
38	YDAT-ADG-38	00208	Gasket
39	YDAT-ADG-39	00209	Clamp Nut
40	YDAT-ADG-40	00211	Cap
41	YDAT-ADG-41	00212	Angle Head
42	YDAT-ADG-42	00213	Grease Cap
43	YDAT-ADG-43	00214	Bearing
44	YDAT-ADG-44	00215	Gear
45	YDAT-ADG-45	00216	Lock Nut
46	YDAT-ADG-46	00217	Work Spindle
47	YDAT-ADG-47	00218	Semi-Round Key
48	YDAT-ADG-48	00219	Collet
49	YDAT-ADG-49	00220	Collet Jacket
50	YDAT-ADG-50	00221	Small Wrench
51	YDAT-ADG-51	00222	Large Wrench