



TWIN/TRIPLE REVERSIBLE DI II I E D

25994



These instructions accompanying the product are the original instructions. This document is part of the product, keep it for the life of the product passing it on to any subsequent holder of the product. Read all these instructions before assembling, operating or maintaining this product.

This manual has been compiled by Draper Tools describing the purpose for which the product has been designed, and contains all the necessary information to ensure its correct and safe use. By following all the general safety instructions contained in this manual, it will ensure both product and operator safety, together with longer life of the product itself.

All photographs and drawings in this manual are supplied by Draper Tools to help illustrate the operation of the product.

Whilst every effort has been made to ensure the accuracy of information contained in this manual, the Draper Tools policy of continuous improvement determines the right to make modifications without prior warning.

1. TITLE PAGE

1.1 INTRODUCTION:

USER MANUAL FOR: Twin/Triple Reversible Puller Stock No: 25994 Part No: N134

1.2 DEVISIONS

TIE TIE VIOIOTO.
Date first published June 2019.

As our user manuals are continually updated, users should make sure that they use the very latest version.

Downloads are available from: http://drapertools.com/manuals

Draper Tools Limited Hursley Road Chandler's Ford Eastleigh Hampshire SO53 1YE

ПK

Website: drapertools.com

Product Helpline: +44 (0) 23 8049 4344 General Fax: +44 (0) 23 8026 0784

General Fax: +44 (0) 23 8026 0784

1.3 UNDERSTANDING THIS MANUALS SAFETY CONTENT:

WARNING! – Information that draws attention to the risk of injury or death.

CAUTION! – Information that draws attention to the risk of damage to the product or surroundings.

1.4 COPYRIGHT © NOTICE:

Copyright @ Draper Tools Limited.

Permission is granted to reproduce this publication for personal and educational use only. Commercial copying, redistribution, hiring or lending is prohibited. No part of this publication may be stored in a retrieval system or transmitted in any other form or means without written permission from Draper Tools Limited.

In all cases this copyright notice must remain intact.

2. CONTENTS 1. TITLE PAGE

2. 3.

6. 7. 8.

TITLE PAGE							
	INTRODUCTION2						
1.2	REVISION HISTORY2						
1.3	UNDERSTANDING THIS MANUAL						
1.4	COPYRIGHT NOTICE2						
	CONTENTS						
2.1	CONTENTS						
	DUCTION						
3.1	SCOPE4						
3.2	SPECIFICATION4						
	NICAL DESCRIPTION						
4.1	IDENTIFICATION4						
4.2	WHAT'S IN THE BOX4						
UNPAC	CKING AND CHECKING						
5.1	PACKAGING4						
PREP/	ARING THE REVERSIBLE PULLER5						
BASIC	REVERSIBLE PULLER OPERATION						
EXPL/	ANATION OF SYMBOLS						
8.1	EXPLANATION OF SYMBOLS						

3. INTRODUCTION

3.1 SCOPE

Puller with a two and three leg option for external and internal pulling of gears, bearings, etc...

100mm

......108mm

3.2 SPECIFICATION

3.2 SELOII ICATION	
Stock No.	25994
Part No.	N134
Maximum Reach	78mm
Maximum Spread	100mm
Two Leg	
Short Leg Reach	82mm
Spread	100mm
Long Leg Reach	100mm
Spread	108mm
Three Leg	
Short Leg	
Reach	82mm 100mm
Long Leg	

4. TECHNICAL DESCRIPTION

4.1 IDENTIFICATION

Reach

Spread



- Hexagon head/striking head.
- Twin head.
- 3 Reversible legs.
- Leg connector.
 Forcing screw.

UNPACKING AND CHECKING

6.1 PACKAGING

Carefully remove the product from the packaging and examine it for any sign of damage that may have happened during shipping. Lay the contents out and check them against the parts shown below. If any part is damaged or missing, please contact the Draper Help Line (the telephone number appears on the Title page) and do not attempt to use the product.

The packaging material should be retained at least during the guarantee period: in case the machine needs to be returned for repair.

Warning! Some of the packaging materials used may be harmful to children. Do not leave any of these materials in the reach of children. If any of the packaging is to be thrown away, make sure they are disposed of correctly, according to local regulations.

6.2 WHAT'S IN THE BOX

As well as the puller, there are several parts not fitted or attached to it.



- 6 Triple head.
- Reversible legs (3rd).
- 8 Leg connector (3rd).

6. PREPARING THE REVERSIBLE PULLER



Twin long leg





Triple long leg



Triple short lea

7. BASIC REVERSIBLE PULLER OPERATION

Information:

- Application of pressure on the forcing screw (5) increases the grip of the self-locking legs 3.
- By reversing the legs the amount of reach and spread can be varied to suit the 2 job. The link nuts 4 of this puller must not be locked tight, as this will prevent the
- self-locking action. 4 Always clean and lubricate the forcing screw before and after use.

INSTRUCTIONS:

3.

- 1. Withdraw the forcing screw (5) to provide sufficient reach.
- 2. Ensure the puller is located at the centre of the workpiece before applying any pressure on the forcing screw.
- 3. Locate the reversible legs 3 around the workpiece. Hand tighten the forcing screw (1). 4. Check that the puller is centrally located and that the forcing screw is lined up
- with the axis of the shaft. 5. Continue to apply pressure using the correct size of spanner or socket on the
- hexagon head ① of the forcing screw.
- 6. Hit the striking head (1) of the forcing screw with a soft faced hammer and then re-tighten with a spanner or socket.
- Continue this operation until the workpiece is removed.

Important: Trying to remove items by using the forcing screw alone will stress the triple head and screw thread causing damage. For detailed and concise instructions on the correct use of this tool, refer to the vehicle manufacturer's handbook.

Safety First:

- Ensure the tool is fitted squarely to workpiece. i.
- Do not use excessive pressure. ii.
- iii. Avoid injury or damage due to sudden release of pressure or resistance.
- Attempt to cover the puller and item being pulled as a precaution against flying iv. debris. Take precautions against any sudden loss of balance caused by the release of
- pressure vi. Wear personal protective equipment (PPE). Wearing approved safety goggles.

8. EXPLANATION OF SYMBOLS

8.1 EXPLANATION OF SYMBOLS



Read the instruction manual.



Wear face mask and safety glasses.

CONTACTS

Draper Tools Limited, Hursley Road, Chandler's Ford, Eastleigh, Hampshire. SO53 1YF. U.K.

Helpline: (023) 8049 4344

Sales Desk: (023) 8049 4333

Internet: drapertools.com

E-mail: sales@drapertools.com

General Enquiries: (023) 8026 6355

Service/Warranty Repair Agent:

For aftersales servicing or warranty repairs, please contact the Draper Tools Helpline for details of an agent in your local area.

TOOR DRAFER STOCKIST

DBKC0719

@Published by Draper Tools Limited.

VOLUE DE LEER OTOOMOT

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical photocopying, recording or otherwise without prior permission in writing from Draper Tools Ltd.