




Determining
the spindle
length



B-7840 spindle

Versions / Order numbers

Square spindle	Order number*
8 mm	B-78400-0 □ -0-1
9 mm	B-78400-1 □ -0-1
□	Length (L) in mm
5	50 (only square 9)
8	65 (only square 9)
9	70 (only square 9)
B	80 (only square 9)
D	90 (only square 9)
F	100
I	115
L	130
O	145
R	160 (only square 9)
W	190 (only square 9)

*Ordering example

B-7840 spindle

Square 8 mm = B-78400-0 □ -0-1


Length in mm (L) 100 mm = F [refer to table]

Length in mm (L)

B-78400-0 □ -0-1 = order number B-78400-0F-0-1



Determining
the spindle
length



* Push bar: min. 7
max. 10
* Touch bar: min. 15
max. 20

B-7841 entrance set spindle

Versions / Order numbers

Square spindle	Order number*
8 mm	B-78410-0 □ -0-1
9 mm	B-78410-1 □ -0-1
□	Length (L) in mm
5	50 (only square 9)
7	60 (only square 9)
9	70
A	75
C	85
E	95
F	100
G	105
I	115
M	135

*Ordering example

B-7841 spindle

Square 8 mm = B-78410-0 □ -0-1

Length in mm (L) 100 mm = F [refer to table]

Length in mm (L)

B-78410-0 □ -0-1 = order number B-78410-0F-0-1