

## blueMatic AV2-E

### Wiring Options




Winkhaus UK Ltd

2950 Kettering Parkway, Kettering,  
Northants NN15 6XZ  
Tel: +44 (0)1536 316000  
Fax: +44 (0)1536 416516

[www.winkhaus.co.uk](http://www.winkhaus.co.uk)  
email: [enquiries@winkhaus.co.uk](mailto:enquiries@winkhaus.co.uk)

## AV2-E Entrance Door Lock Wiring diagram for Access Control



## AV2-E Entrance Door Lock Wiring diagram for Push Switch

