

King Pin Lock Fitting Instructions



- 1. Remove the black PVC cover.
- 2. Remove the lock bar from the King Pin Lock by inserting key, rotating 1/4 turn anti-clockwise, and withdraw lock.
- 3. Offer the casting up to the King Pin, insert the lock bar, and rotate key 1/4 turn clockwise to lock.

<u>TIP</u>

If the shallow PVC cover is left under the King Pin casting as the lock is fitted and removed this will prevent grease getting on your hands.

To prevent access to the King Pin attachment bolts, disc part number KP800 may be purchased

We have taken every care in the design and manufacture of this security device and we believe that it is an effective deterrent. However we cannot guarantee that it will resist the efforts of the most determined thief, and as such we do not accept any liability for loss or damage caused by theft, vandalism or other illegal activity against property to which This this device is fitted.

Bulldog Security Products

Units 1 - 4 Stretton Road, Much Wenlock, Shropshire, TF13 6DH. Tel: 01952 728171 Fax: 01952 728117 Email sales@bulldogsecure.com www.bulldogsecure.com KP01-3 Lock Lubrication.

IMPORTANT - To ensure free movement of the lock, spray lock mechanism & ball bearings with WD40 (or equivalent) minimum every four months.