



MARTHA PENDANT LAMP

ASSEMBLY GUIDE



www.furniturebox.co.uk

Scan QR code for more tips,
advice and assembly video or visit
furniturebox.co.uk/club/marthapendantlamp

Important - Please read these instructions fully before starting assembly



SAFETY AND CARE ADVICE



NO POWER TOOLS

SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- We recommend seeking assistance from a qualified electrician for this installation.
- The lamp must be protected by a 3 amp fuse in the main plug. This lamp can only be used with a 220V~240V 50Hz power source
- Intended for indoor use and must not be used in bathrooms or near any liquids
- Do NOT turn on or use with product until it has been completely assembled and the light bulb has been installed. During assembly or maintenance, make sure the lamp is disconnected from the mains.
- Under no circumstances must this light fixture be covered with any type of material or have anything hung from any part of the lamp. Covering the lamp could pose a safety hazard.
- If the external flexible cord or switch of the lamp is damaged, do NOT use the lamp under any circumstances.
- Waste electrical products cannot be disposed of with normal household waste. Please check with your local authority for your nearest recycling centre that accepts electrical products.
- When replacing the light bulb, make sure the lamp is switched off at the mains plug to allow it to cool down. (CAUTION: light bulbs get hot during use).
- If you have any doubt about installation/use of the lamp, consult a qualified electrician.



Follow us on Instagram
@furniturebox_uk

IMPORTANT INFORMATION




15 MINUTE
BUILD



ONE
PERSON

SAFETY AND CARE ADVICE (CONTINUED)

- Make sure to use the correct wattage and type of light bulb for the lamp. Using light bulbs of a higher wattage than the lamp requires can cause a safety hazard and may cause damage to the lamp. Lamp requires:




(bulbs not included)

- Always shut off power to the circuit before starting installation work.
- This fitting must be earthed.
- Connect the earth conductor of your house wiring (normally bare or with Green/Yellow sleeving) to the earth terminal of the fitting marked "E", "Earth" and/or coloured Green/ Yellow. Connect the switched live conductor of your house wiring (normally Brown or Red) to the live terminal or wire which is marked "L" or "Live" and/or coloured Brown. Connect the neutral conductor of your house wiring (normally Blue or Black) to the neutral terminal or wire which is marked "N" or "Neutral" and/or coloured Blue.
- Double check all the connections are secure and that no loose strands of wire are left out of the connector.
- The minimum distance from lighted object is 0.3M.
- The weight of the lamp must be taken by the suspension wire. When adjusting the cable make sure that it is longer than the wire.
- Incorrect assembly and/or use of the lamp will void the warranty.

We recommend you seek professional assistance from a qualified electrician for this installation.


STEP 1


Attach the bracket to the ceiling around your electrical wiring. Use 2x raw plugs H1 and 2x screws H2 to secure bracket.



STEP 2

Wire in the pendant as shown.





STEP 3



Place the pendant cap over the bracket and secure by tightening the screws on either side into the bracket.

STEP 4

Carefully insert the bulb into the socket. You will need 1x G9 bulb (not included). Be careful to align the pins of the bulb into the socket holes.

STEP 5

Carefully place the lampshade over the bulb and twist to secure.



NOTE: The quantities above are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



furniturebox



WE **LOVE** INTERIORS! SHARE
YOURS WITH US ON SOCIAL MEDIA

1. follow us on Instagram
2. post your interior
3. tag us to be featured



@furnitureboxUK



@furniturebox_uk




@furnitureboxuk

www.furniturebox.co.uk

LOOKING GOOD!

Now you've assembled your product find out how to care for your item and keep it looking brand new.



Look for your care guide in the box or visit:
www.furniturebox.co.uk/club/care-guide



OUR 2 YEAR* GUARANTEE

our products come with a 2 year guarantee
to give you peace of mind shopping at
Furniturebox

*excludes some garden furniture items
which have a 1 year guarantee



WHAT THE GUARANTEE COVERS



PRE-INSERTED FIXINGS

e.g. loose metal threads



FAULTY JOINTS

e.g. legs bending



EXTERNAL FIXING FAULTS

e.g. bonding/glue



STRUCTURAL INTEGRITY

e.g. the frame of the
product



ACTIVATE YOUR GUARANTEE ONLINE

scan this QR code with your phone to read
the full guarantee online and register your
product. It only takes a moment to fill out.
Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Unit 6, St Modwen's Park,
Chippenham, SN15 5BD
Tel: 01747 863333 Email: sales@furniturebox.co.uk