


EMILY CEILING LIGHT

ASSEMBLY GUIDE



www.furniturebox.co.uk

Scan QR code for more tips,
advice and assembly video or visit
furniturebox.co.uk/club/general-club-page

Important - Please read these instructions fully before starting assembly



**SAFETY AND
CARE ADVICE**



NO POWER TOOLS

SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Under no circumstances must this light fitting be covered with any type of material or have anything hung from any part of the light fitting. Covering the light could pose a safety hazard.
- If any wires or cords for the light are damaged, do NOT use under any circumstances.
- Waste electrical products cannot be disposed of with normal household waste. Please check with your local authority for your nearest recycling centre that accepts electrical products.
- When replacing the light bulb, make sure the light is switched off and the bulb has cooled. (CAUTION: light bulbs get hot during use)



Follow us on Instagram
@furniturebox_uk

IMPORTANT INFORMATION



20 MINUTE
BUILD



ONE
PERSON

SAFETY AND CARE ADVICE (CONTINUED)

- **Make sure to use the correct wattage and type of light bulb for the lamp. Using light bulbs of a higher wattage than the lamp requires can cause a safety hazard and may cause damage to the lamp.**
- To clean the lamp, use a dry clean cloth ONLY. Do NOT use any liquids or cleaners on the lamp. If any liquids are spilt on the lamp, stop using immediately and contact a qualified electrician for advise.
- If you have any doubt about installation/use of the lamp, consult a qualified electrician.
- Always shut off power to the circuit before starting installation work.
- This fitting must be earthed.
- Connect the earth conductor of your house wiring (normally bare or with Green/ Yellow sleeving) to the earth terminal of the fitting marked "E", "Earth" and/or coloured Green/ Yellow. Connect the switched live conductor of your house wiring (normally Brown or Red) to the live terminal or wire which is marked "L" or "Live" and/or coloured Brown. Connect the neutral conductor of your house wiring (normally Blue or Black) to the neutral terminal or wire which is marked "N" or "Neutral" and/or coloured Blue.
- Double check all the connections are secure and that no loose strands of wire are left out of the connector.
- Incorrect assembly and/or use of the lamp will void the warranty

Contents

1 x Light Fitting - Including:

1 x Fixing Bracket

Side Screws


Lock Washers.

1 x Fixing Pack - Containing:

3-way Connection Block

2 x Fixing Screws

2 x Plugs.



STEP 1

Ensure the house electricity is off at the fuse board

STEP 2

If you are fitting this product in place of an existing one, you may find that there are more than 3 sets of cables connected. If there are loops in cables that are not connected to the light these must be terminated in a separate terminal block not connected to the fitting. Before removing existing fitting, carefully note position of each set of cables.

STEP 3

Carefully remove the mounting bracket from the ceiling cup by removing the 2 screws located in the side.

STEP 4

Using the mounting bracket as a template, mark and drill fixing holes in the ceiling. Ensure the holes are drilled into a joist or other suitable mounting and not just into plaster.

STEP 5

Secure the mounting bracket to the surface using suitable fixings for the type of material. The height of the drop may be adjusted prior to electrical installation. Insert steel wire into the ceiling cup until the desired length is achieved. Any excess cable should be neatly tucked away into the ceiling void.

STEP 6

The weight of the fitting must be supported whilst making the electrical connections as follows:

Household circuit


Fitting wire

Blue or Black (Neutral)connect to.....Blue or wire marked "N"

Red or Brown Switched Live.....connect to.....Brown or Red wire marked "L"

Green/Yellow sleeved copper (Earth)connect to..... Green/Yellow or wire marked "⏏"

Ensure that all connections are tight and no loose strands are left out of the connector. Snap the cover of the connector block closed ensuring the wires are not trapped. Wrap two layers of electrical insulation tape around the connector block and around the wiring 2cm each side of the connector block - (see Fig 2.)



STEP 7

Offer fitting up to the mounting bracket and secure in place using the screws removed earlier. Take care not to damage wiring.

STEP 8


Fit the bulb: Type and wattage as indicated on the fitting. The wattage indicated must not be exceeded.

STEP 9

Switch on the electricity supply at the fuse board and enjoy using your new light!

LOOKING GOOD!

Now you've assembled your product find out how to care for your item and keep it looking brand new.



Look for your care guide in the box or visit:
www.furniturebox.co.uk/club/care-guide



OUR 2 YEAR GUARANTEE

our products come with a 1 year guarantee
to give you peace of mind shopping at
Furniturebox



WHAT THE GUARANTEE COVERS



PRE-INSERTED FIXINGS
e.g. loose metal threads



FAULTY JOINTS
e.g. legs bending



EXTERNAL FIXING FAULTS
e.g. metal discs removing
from table top



STRUCTURAL INTEGRITY
e.g. the frame of the
product



ACTIVATE YOUR GUARANTEE ONLINE

scan this QR code with your phone to read
the full guarantee online and register your
product. It only takes a moment to fill out.
Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, St Modwen's Park,
Chippenham, SN15 5BD
Tel: 01747 863333 Email: sales@furniturebox.co.uk