

Double switch 10AX 250V~ with Push&Go mounting system graphite Simon 24 Harmonie

REF. 2420398-038



BASIC INFORMATION

FINISH

Graphite

ETIM CLASS

EC001590

TECHNICAL INFORMATION

NUMBER OF CONTACTS

3

IP RATING

IP20

RAL

7021

CURRENT (A)

10 AX

MAINTENANCE

Clean with a soft, dry cloth. Do not use abrasive cloths or cleaning products that contain chlorine.

VOLTAGE (V~)

250 V~

INSTALLATION AND MAINTENANCE

CABLE STRIPPING NECESSARY (MM)

14

CLAW

Push&Go

TYPE OF TERMINAL CONNECTION - FUNCTION 1

Fast

LOGISTICS INFORMATION

UNITARY EAN CODE

8421053326572

UNITARY PACKAGING GROSS
WEIGHT

0.052

PACKAGING LENGTH

0

UNITARY PACKAGING HEIGHT

0

PRODUCT NET WEIGHT

0.052

PACKAGING MEASUREMENT
UNIT

MMT

UNITARY PACKAGING WIDTH

0

UNITARY PACKAGING WEIGHT
UNIT

KGM

PACKAGING VOLUME

0

UNITARY PACKAGING LENGTH

0

PACKAGING EAN

8421053326589

PACKAGING VOLUME UNIT

MMQ

UNITARY PACKAGING
MEASUREMENT UNIT

MMT

UNITS CONTAINED PACKAGING

10

PACKAGING GROSS WEIGHT

0

UNITARY PACKAGING VOLUME

0

PACKAGING HEIGHT

0

PACKAGING NET WEIGHT

0.52

UNITARY PACKAGING VOLUME
UNIT

MMQ

PACKAGING WIDTH


0

PACKAGING WEIGHT UNIT


KGM

MECANISMOS SIMON 31, 75, 77, 82 Y 88


Mecanismos básicos / Basic switches




Interrupor unipolar / Single-pole switch
XXXX101-XXX




Interrupor unipolar / Single-pole switch
7700101-039




Pulsador / Push button switch
XXXX150-XXX




Pulsador / Push button switch
7700150-039




Interrupor bipolar / Double pole switch
XXXX133-XXX




Conmutador / 2-way switch
XXXX201-XXX




Conmutador / 2-way switch
7700201-039




Conmutador cruce / Intermediate switch
XXXX251-XXX




Conmutador cruce / Intermediate switch
7700251-039




Grupo 2 interruptores / 2 switches group
XXXX398-XXX




Pulsador desconexión / Push button disconnection switch
XXXX152-XXX




Grupo dos conmutadores / 2-way switches group
XXXX397-XXX




Grupo de pulsadores desconexión / Push button switch
desconexion group XXXX395-XXX




Grupo conmutador y pulsador / 2-way and push button switch group
XXXX301-XXX




Interrupor unipolar / Single-pole switch
XXXX102-XXX




Interrupor con piloto / Push button pilot switch
7700112-039




Interrupor bipolar / Double pole switch
XXXX134-XXX




Conmutador / 2-way switch
XXXX202-XXX




Interrupor unipolar con luminoso / Single-pole switch with light
XXXX104-XXX




Pulsador con luminoso / Push button switch with light
XXXX160-XXX



Pulsador con luminoso / Push button switch with light
7700160-039



Conmutador con luminoso / 2-way switch with light
XXXX204-XXX



Conmutador cruce con luminoso / Intermediate switch with light
XXXX254-XXX