



MECANISMOS SIMON 31, 75, 77, 82 Y 88


Mecanismos básicos / Basic switches




Interruptor unipolar / Single-pole switch
XXXX101-XXX




Interruptor unipolar / Single-pole switch
7700101-039




Pulsador / Push button switch
XXXX150-XXX




Pulsador / Push button switch
7700150-039




Interruptor bipolar / Double pole switch
XXXX133-XXX




Conmutador / 2-way switch
XXXX201-XXX




Conmutador / 2-way switch
7700201-039




Conmutador cruce / Intermediate switch
XXXX251-XXX




Conmutador cruce / Intermediate switch
7700251-039




Grupo 2 interruptores / 2 switches group
XXXX398-XXX




Pulsador desconexión / Push button disconnection switch
XXXX152-XXX




Grupo dos conmutadores / 2-way switches group
XXXX397-XXX




Grupo de pulsadores desconexión / Push button switch disconnection group
XXXX395-XXX




Grupo conmutador y pulsador / 2-way and push button switch group
XXXX301-XXX




Interruptor unipolar / Single-pole switch
XXXX102-XXX




Interruptor con piloto / Push button pilot switch
7700112-039




Interruptor bipolar / Double pole switch
XXXX134-XXX




Conmutador / 2-way switch
XXXX202-XXX




Interrupor unipolar con luminoso / Single-pole switch with light
XXXX104-XXX




Pulsador con luminoso / Push button switch with light
XXXX160-XXX



Pulsador con luminoso / Push button switch with light
7700160-039



Conmutador con luminoso / 2-way switch with light
XXXX204-XXX



Conmutador cruce con luminoso / Intermediate switch with light
XXXX254-XXX