



INSTALLATION MANUAL

Eastbrook Road, Gloucester GL4 3DB
 Technical Helpline: 01452 317890
 email: technical@eastbrookco.com














Eastbrook Code	Adjustment	Eastbrook Code	Adjustment
69.0047	490-500	69.0048	690-700
69.0049	750-760	69.0050	790-800
69.0051	890-900	69.0052	990-1000
69.0053	1190-1200	69.0054	1390-1400










F010



This product should only be fixed by a fully qualified installer


8CE1  1X	8CE2  5X	8CE3  30 ST4 5X	8CE4  3X	8CE5  10 ST4 3X	8CE7  1X	8CE8  16 ST4 1X
8CE9  1X	8CE10  12 ST4 3X	8CE11  2X	8CE12  1X	8CE13  1X	8CE14  1X	




Ø6



Ø3.2





LH



RH

1L





12mm

1.1

8CE1

1R




12mm


1.1

8CE1

2L




2.1




8CE2(4X)


2.2



2R




2.1





8CE2(4X)



2.2





3L





3R





4L





4R




5L



5R



6L




6.1


8CE13

6.2

6.3



6R




6.1


8CE13

6.2


6.3




7L




7.1




7R




7.1




8L




8.1




8.2




8.3




8R




8.1





8.2





8.3





9L





9R





10L





10R




11L




11R




12L




12.1




12.2




12.3




12R




12.1




12.2




12.3




13L




13.1




13.2




13.3




13R




13.1



13.2





13.3




14L

Silicone on the outside of the screen only





14.1




14R

Silicone on the outside of the screen only



14.1



Cleaning & Maintenance

Don't clean the shower enclosure with irritant detergent such as alcohol,bleach or other chemical cleaners.

Only clean with warm soapy water.

After the installation is completed,should you find that there is notable noise when the glass door moves,you may add a small quantity of lubricant onto the roller wheel,slipping hook and the track.

Helpline: 01452 317890