



INSTALLATION MANUAL









Eastbrook Code	Adjustment	Eastbrook Code	Adjustment
69.0075	960-1000	69.0077	1160-1200
69.0078	1360-1400		






This product should only be fixed by a fully qualified installer

<p>SD17</p> <p>1X</p>	<p>SD8</p> <p>1X</p>	<p>SD27</p> <p>1X</p>	<p>SD2</p> <p>1X</p>	<p>SD11</p> <p>1X</p>	<p>SD6</p> <p>13X</p>
<p>SD5</p> <p>1X</p>	<p>SD4</p> <p>1X</p>	<p>SD12</p> <p>2X</p>	<p>SD23</p> <p>1X</p>	<p>SD18</p> <p>1X</p>	<p>SD21</p> <p>1X</p>
<p>SD1</p> <p>25 ST4 2X</p>	<p>SD3</p> <p>30 ST4 12X</p>	<p>SD13</p> <p>10 ST4 13X</p>	<p>SD24</p> <p>30 ST4 4X</p>	<p>SD20</p> <p>1X</p>	<p>SD19</p> <p>2X</p>
<p>SD25</p> <p>1X</p>	<p>SD22</p> <p>1X</p>	<p>SD9</p> <p>2X</p>	<p>SD26</p> <p>1X</p>	<p>SD14</p> <p>1X</p>	<p>SD10</p> <p>8X</p>




ø6




ø3.2


1




2




3




4




5




6




7




8




9




10




11




12




13




14




15




16




17




18



19



20



Silicone on the outside of the screen only

Cleaning & Maintenance

Don't clean the shower enclosure with irritant detergent such as alcohol,bleach or other chemical cleaners.

Only clean with warm soapy water.

After the installation is completed,should you find that there is notable noise when the glass door moves,you may add a small quantity of lubricant onto the roller wheel,slipping hook and the track.

Helpline: 01452 317890