





Spare parts



Tools Required



drill bit (Ø6mm)



Silicone gun



Pencil



screwdriver



Drill machine




Level ruler




Rubber hammer


1




2




3



4



5



Cleaning & Maintenance

Don't clean the shower enclosure with irritant detergent such as alcohol, bleach or other chemical cleaners.

Only clean with warm soapy water.

After the installation is completed, should you find that there is notable noise when the glass door moves, you may add a small quantity of lubricant onto the roller wheel, slipping hook and the track.

Helpline: 01452 317890

Please ensure silicone sealant is on the outside only.

Eastbrook