



Water Closet & Flushometer Combo

WETS-2002.1303

Product description

Standard, ST-2009 Water Closet and ECOS 111 Flushometer.

Compliances & Certifications



(BREEAM Water Credit, EPD, Green Globes Water, HPD, IAPMO, cUPC Certified, WELL Building Standard)

Code 20021303

Downloads

- [Royal Exposed Installation Instructions.pdf](#)
- [HET Top Spud Installation Instructions.pdf](#)
- [EBV-500_550-A Installation Instructions.pdf](#)
- [SS:ST:SU:WETS:WEUS Fixtures Repair and Maintenance Guide.pdf](#)
- [ECOS HW Repair and Maintenance Guide.pdf](#)
- [Fixture Brochure.pdf](#)
- [Additional Downloads](#)

Videos

- [Sloan – Company Overview](#)

Details

- Flush Volume: 1.6/1.1 gpf

Features

- Automatically initiates a 1.1 gpf or 1.6 gpf flush based on how long the user remains in sensor range
- Buttons on top of the flush valve enable manual flushing with a full or reduced flush at restroom visitor's discretion
- Employs an infrared sensor with multiple-focused, lobular sensing fields for high and low target detection
- User-friendly, three-second flush delay
- High copper, low zinc brass castings for dezincification resistance
- Fixed metering bypass and no external volume adjustment to ensure water conservation
- Valve body, Cover, Tailpiece and Control Stop shall be in compliance with ASTM Alloy Classification for Semi-Red Brass
- Valve shall be in compliance to the applicable sections of ASSE 1037
- Designed to maximize and complement Sloan flushometers
- Universal model works with Sloan flushometers from 1.1 to 1.6 gpf
- Durable, hygienic vitreous china construction with elongated rim
- Syphon jet flushing achieves 1000g Map Scores when used with Sloan flushometers
- IAPMO certified to meet or exceed ASME A112.19.2 standards
- WaterSense compliant when used with a WaterSense compliant flushometer

Components

- Flushometer: Code 3370420
- Water Closet: Code 2102009

Warranty

[View Warranty Information](#)

Notes

All information contained within this document subject to change without notice.

Static load tested according to the procedure outlined in Section 6.7 of ASME A112.19.2. Not recommended for bariatric use.

