

OPTIONS

Flush Volume

1.6 gpf (6.0 Lpf) (1.6) 3.5 gpf (13.2 Lpf) (3.5)

Water Efficiency

Low Consumption Water Saver

Push Button

Fixture Wall Actuator (FW)
Side Wall-Mounted Actuator (SW)

Offset

1 ½" (38mm) (1-1/2-OFST)

Outlet Tube

Trap Primer (TP)

Compliances & Certifications

ADA Compliant BAA Compliant BABAA Compliant UPC Certified cUPC Certified

NOTES

For product line drawings, view model-specific spec sheets.

All information contained within this document subject to change without notice.



DESCRIPTION

Royal® Exposed Manual Specialty Water Closet Bedpan Washer/Hydraulic Flushometer

FEATURES

- Exposed water closet, diaphragm model, chrome-plated hydraulic actuated water closet Flushometer for floormounted or wall-hung top spud bowls
- Operates by means of a push button with an ADA-compliant, non-hold-open feature type actuator to ensure water conservation
- Presents a leaner, more aesthetic installation, reducing possible bacteria growth on hidden and hard-to-reach surfaces found on other bedpan washer units
- Eliminates the need for unsanitary hose sprays, as well as the additional housekeeping that hoses require and the potential for patient slippage
- Incorporates a patented one-piece construction body design, maintaining the spray arm in an upright position
- Valve body, stop body, diverter body and diverter pivot made from brass casting using semi-red brass for durability and long life
- PERMEX synthetic rubber diaphragm with Dual Filtered Fixed Bypass
- Valve body, Cover, Tailpiece and Control Stop shall be in compliance with ASTM Alloy Classification for Semi-Red Brass
- Valve shall be in compliance to the applicable sections of ASSE 1037.

DOWNLOADS

- BPW Exposed Installation Instructions
- Control Stop Repair and Maintenance Guide
- Flush Connections Flanges Repair and Maintenance Guide
- Tail Piece Repair and Maintenance Guide
- Royal Manual Diaphragm Flushometer Repair and Maintenance Guide
- Slimline Bedpan Washer Repair and Maintenance Guide





- Series 900 Flushometers Repair and Maintenance Guide
- Hydraulic Push Button Options
- Additional Downloads

Sloan 10500 Seymour Ave, Franklin Park, IL 60131 Phone: 800.982.5839 • Fax: 800.447.8329 • sloan.com