


RES-LOK - FITTING INSTRUCTIONS







STEP 1 Select correct hand of RES-LOK to suit application (L. Hand shown).

STEP 2 Fit RES-LOK to the frame using suitable screws and into reenforcement where possible. Note. To give best access for un-locking, fit the RES-LOK towards the back of the frame.

Position the stud plate on the sash Note The stud plate must be positioned so that it is inline with the RES-LOK when the window is closed (see fig 3) and the stud is inline with the alignment mark on the RES-LOK. Fit using suitable screws and into re-enforcement were possible.

NOTE.
On certain window profiles with deep locating ribs in the frame section, it may be necessary to locally remove a small section of these ribs to allow free movement of the stud into the frame.