



INSTALLATION MANUAL

Eastbrook Code	Adjustment	Eastbrook Code	Adjustment
69.0069	970-1000	69.0070	1070-1100
69.0071	1170-1200	69.0072	1370-1400
69.0073	1570-1600		





B532




This product should only be fixed by a fully qualified installer

S01 2X	S02 1X	S03 2X	S04 1X	S05 2X	S06 ST4 2X
S07 3X	S08 2X	S09 1X	S10 1X	S11 14X	S12 ST4 6X
S13 8X	S14 ST4 16X	S15 2X			




L




R



L-1





R-1






L-2






R-2





L-3





R-3






L-4






R-4







L-5







R-5








L-6








R-6




L-7




R-7




L-8




R-8




L-9




R-9






L-10






R-10







L-11







R-11






L-12






R-12




L-13




R-13




L-14




14.1




14.2




R-14




14.1



14.2



L-15



Silicone on the outside of the screen only

C l e a n i n g & M a i n t e n a n c e

Don't clean the shower enclosure with irritant detergent such as alcohol,bleach or other chemical cleaners.

Only clean with warm soapy water.

After the installation is completed,should you find that there is notable noise when the glass door moves,you may add a small quantity of lubricant onto the roller wheel,slipping hook and the track.

Helpline: 01452 317890