

Wall Fixing Set inludes;	
4	Bracket (a)
4	Plastic buffer (b)
8	Wall Screw (c)
8	Wall Plug (d)
1	Flow Diverter (e)





\*Diverter should be installed into the flowside of the radiator.

Install the flow diverter

Between the first and second profile

**Profile Quantity** 

of radiator

2



### **CONGRATULATIONS**

You are the proud owner of an exclusive Preston Aluminium Radiator which has been specially produced by our craftsmen who would wish you to enjoy many years of satisfaction from it.

#### **INSTALLATION**

This product must be installed by a fully qualified engineer.

- Please consider using an Eastbrook Valve Set this will ensure that your radiator looks its best with matching radiator valves.
- On commissioning, flush the central heating system thoroughly using a proprietary solution to
  ensure that aggressive substances such as fluxes and manufacturing residue, from which internal
  surfaces of your radiator can sustain irreparable damage are removed. It is further
  recommended that an appropriately approved corrosion inhibitor be subsequently added to the
  heating system in order to protect the radiator and other parts of the central heating system to
  promote extended operating lifespan.

### **MAINTENANCE**

- From time to time it is advisable to clean your towel rail with a warm damp cloth. Never use any form of abrasive cleaner or chemical.
- Corrosion inhibitor must also be regularly maintained, please consult your engineer for details.

## **IMPORTANT**

- Maximum working pressure of this radiator is 4 bar.
- This radiator is to be used on Domestic Central Heating systems only. (Not suitable for use on direct hot water systems). Please consult your engineer or supplier.

# **WARRANTY**

Your Preston Aluminium Radiator is fully warranted for five years in respect of defective materials and workmanship and subject to installation being carried out by a qualified engineer in accordance with good practice and corrosion inhibitors being regularly maintained.

**REMEMBER** ..... Excellence is worth looking after.

HELPLINE Phone : 01452 317890
HELPLINE email : technical@eastbrookco.com