



SOLIS® Sensor Flushometer

SOLIS 8111 TRK

Product description

SOLIS® Exposed Sensor Water Closet Run-on Detector Flushometer.

Finish



Available in Polished Chrome (CP).

Connectivity

Downloads

- [Solis 8100 Series Installation Instructions](#)
- [Sloan Track-on Run-on Detector V700AA Vacuum Breaker Tube - Flushometer Retrofit Installation Instructions](#)
- [Sloan Track-on Run-on Detector Sell Sheet](#)
- [Additional Downloads](#)

Videos

- [Sloan Track-on Run-on Detector - Flushometer or Vacuum Breaker Retrofit](#)
- [Sloan - Company Overview](#)

Features

Solar Powered- The sensor assembly is powered by a solar cell.

- Main Seat, Stop Seat and Vacuum Breaker Molded from PERMEX® Rubber Compound for Chloramine resistance
- PERMEX® Synthetic Rubber Diaphragm with Dual Filtered Fixed Bypass
- “Low Battery” Flashing LED
- Sweat solder adapter with cover tube and cast wall flange with set screw
- Four (4) Size AA Battery Power Source
- Operates by means of an infrared sensor with multiple-focused, lobular sensing fields for high and low target detection
- Engineered Metal Cover with replaceable Lens Window
- Fixed Metering Bypass and No External Volume Adjustment to Ensure Water Conservation
- High copper, low zinc brass castings for dezincification resistance
- Courtesy Flush Override Button
- Valve body, Cover, Tailpiece and Control Stop shall be in compliance with ASTM Alloy Classification for Semi-Red Brass
- Valve shall be in compliance to the applicable sections of ASSE 1037

Battery Specifications

Usage	4-AA Battery Service Life†			
	24 yrs	18 yrs	9 yrs	7.2 yrs
per month	500	1,000	3,000	4,000
per day	25	50	150	200

† Service life varies according to actual usage and restroom conditions
Battery shelf life: Alkaline= ~10 years - Lithium= ~25 years

* Service life varies according to actual usage & restroom conditions
Battery shelf life: Alkaline= ~10 years - Lithium= ~25 years

Warranty

[View Warranty Information](#)

Notes

All information contained within this document subject to change without notice.