

## INSTRUCTION MANUAL for VELINO STAINLESS STEEL TOWEL RAIL



### PLEASE READ THIS INSTRUCTION THOROUGHLY BEFORE STARTING THE INSTALLATION

- The product that you are about to install should only be used in DOMESTIC CENTRAL HEATING systems unless the size you purchased is compatible with element for electric only usage. Please consult your engineer or supplier.
- Max. Working pressure : 4 bar
- Our products are designed to be fitted by a fully qualified installer and in compliance with all relevant regulations.
- Eastbrook will not accept any liability for damage, injury or unsatisfactory performance if the product is not fitted by a fully qualified installer.

### INSTALLATION

- This product must be installed by a fully qualified engineer.
- Please consider using an Eastbrook Valve Set - this will ensure that your radiator looks its best with matching radiator valves.
- On commissioning, flush the central heating system thoroughly using a proprietary solution to ensure that aggressive substances such as fluxes and manufacturing residue, from which internal surfaces of your radiator can sustain irreparable damage - are removed.

**Only when fitted on indirect heating systems :** It is recommended that an appropriately approved corrosion inhibitor be subsequently added to the heating system in order to protect the radiator and other parts of the central heating system to promote extended operating lifespan. Please ensure, when adding inhibitor, not to underdose or overdose and follow the inhibitor instructions. **The Ph level** of the system water should be between 6.5 and 7.5  
*If the system water is too acidic then the metals in the system would corrode. If the system water is too alkaline, then there is a higher risk of electrolysis.*

### MAINTENANCE

This towel rail is manufactured from Grade 304 Stainless Steel. The surface of the towel rail should be cleaned regularly with water and either a neutral or slightly alkaline (PH 6-9) liquid detergent (such as most soap solutions and dish washing liquids). Soap and water are usually sufficient for removing dirt, calcium and other deposits. To clean your towel rail, moisten a sponge or tea cloth with diluted detergent and wipe all the surface. Rinse repeatedly with a sponge or tea cloth moistened with lukewarm water. Finish by drying all surface. Never use abrasive cleaning implements, or abrasive or corrosive substances, or substances containing solvents acids or ammonia for cleaning the surface. This towel rail is not intended for use by children unless they are adequately supervised by a responsible person to ensure that they can use it safely.

### WARRANTY

Your Velino Stainless Steel Towel Rail has five years manufacturer's warranty in respect of defective materials and workmanship and subject to installation being carried out by a qualified engineer in accordance with good practice and corrosion inhibitors being regularly maintained, if installed on indirect heating system.

## IMPORTANT NOTES

- Make sure to use PTFE tape around the valve tails (not supplied with the radiator) & bleed valve and blanking plug (supplied with the radiator) before fitting on the radiator. This towel rail has two top inlets and the bleed valve has to used on opposite top inlet from the bottom flow inlet.
- Flow and return can be either side at the bottom.
- Check the wall is strong enough to hold the weight of the radiator that will be filled with water. The supplied wall plugs & screws are suitable for solid brick walls, not plasterboard walls.
- After fitting the valves and plugs, fill the system to check for leaks.
- Run the central heating system and release any trapped air using the air vent (bleed valve) plug.

