

FEATURES



ESD Certified



Fibreglass Toecap



PS Rated Penetration Resistant Insert



Non Metallic



Fuel Oil Resistant Outsole



Heat Resistant Outsole to 300C



Fully Waterproof



Recycled Materials



Scuff Cap



SR Slip Resistance

INDUSTRIES



Agricultural



Construction



Engineering



Highways



House builders



Offshore



Quarry and Mining



Rail



Utilities

Product Details

Colour: Honey
Size Range: UK 6-14
(INC 6.5 and 10.5)
Height: 10 inches
Weight: 1018g



PRODUCT DESCRIPTION

RF880 Exploration: Unleash unparalleled performance with this robust rigger boot. Featuring a cemented and stitched outsole for exceptional longevity, moulded nitrile rubber scuff cap for superior abrasion resistance, waterproof yet breathable construction, and lightweight fibreglass toecap for 200-joule impact protection. Experience ultimate safety with Activ-Step® penetration-resistant midsole and ESD specification, ideal for demanding industrial environments.

MATERIAL BREAKDOWN

UPPER MATERIAL: Water Repellent Waxy Leather, LWG Certified

FOOTBED: Activ-Step® Bio-Based Footbed Made From 73% Natural Rubber, 27% Synthetic Rubber, 100% Post Consumer Recycled Top Mesh

LINING: Waterproof Construction, 40% Nylon, 60% Post Consumer Recycled Polyester

SCUFF CAP: Nitrile Rubber (Integrated within Outsole)

OUTSOLE: Nitrile Rubber

PROTECTIVE TOECAP: Fibreglass

PROTECTIVE MIDSOLE: Activ-step® PS Rated Penetration Resistant Insert

TECHNOLOGIES & ACCREDITATIONS



| Category | SB | S1 | S2 | S3/L/S | S4 | S5/L/S | S6 | S7/L/S |
|-------------------------------------|----|----|----|--------|----|--------|----|--------|
| Class 1 | ✓ | ✓ | ✓ | ✓ | ✗ | ✗ | ✓ | ✓ |
| Class 2 | ✗ | ✗ | ✗ | ✗ | ✓ | ✓ | ✗ | ✗ |
| 200 Joules Toecap | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| Closed heel Area | ✗ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| Energy Absorption Of Seat Region | ✗ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| Anti-Static | ✗ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |
| Water Penetration And Absorption | ✗ | ✗ | ✓ | ✓ | ✗ | ✗ | ✓ | ✓ |
| Perforation Resistance To The Type | ✗ | ✗ | ✗ | ✓ | ✗ | ✓ | ✗ | ✓ |
| Cleated Outside | ✗ | ✗ | ✗ | ✓ | ✗ | ✓ | ✗ | ✓ |
| Water Resistance Of The Entire Shoe | ✗ | ✗ | ✗ | ✗ | ✗ | ✗ | ✓ | ✓ |

EN 2022 SPECIFICATION

Safety footwear is classified in the UK and EU by the EN 20345 standard using a categorisation of S1 through to S7 to quickly determine the level of incorporated safety components. This is further supported by letter codes for additional safety components or tests the footwear has undergone.

For further information contact the Rock Fall sales team.

Always check with your health and safety management if you are unsure of the appropriate specification required by your workplace.

Class 1 refers to footwear made from leather & other materials, excluding all polymeric and all rubber footwear
Class 2 Refers to all polymeric footwear including all rubber footwear.

S3, S5, S7 Specify metallic midsole tested at 1100N.

S3L, S5L, S7L specify non-metal midsole tested at 1100N with a 4.5mm nail.

S3S, S5S, S7S specify non-metal midsole tested at 1100N with a 3mm nail.

Please note that the EN20345:2022 specification does not necessarily apply to the footwear represented here, and that there are further specifications attaining to specific safety tests and standards. Always check specification and standards of the footwear before purchase. For more information on specifications and standards, get in touch with our team for complete guide.

WELLBEING & COMFORT

When you spend your working day on your feet, discomfort and incorrect footwear can cause serious long-term issues. That's why our footwear is designed to support your feet where they need it most, and we have a wide variety of styles to fit every kind of foot. Make sure your footwear is providing the correct arch support, and that your footwear is the correct size for your feet.

FOOTWEAR CARE

Keeping your safety footwear in a good condition helps keep them comfortable and extend their useful life. Always make sure to keep the upper and sole clear of extensive mud or residue, using a brush and warm water to clean. Never dry out footwear using heat (such as placing them near a radiator) always allow them to dry naturally. Use a leather nourishment or dubbin wax to keep leather materials from drying out.

